

START RIGID - rigidní podlahy

START RIGID 601708, 601718, 601727, 601733, 601742, 690207, 611571, 601955, 620506, 620507
621102, 621104, 608006, 608016

START VINYL / START VINYL PRO - vinylové podlahy

START VINYL 1042, 1043, 1044, 1045, 1046, 3204, 3205, 3236, 3239, 3262, 3263, 3267, 3282, 3301
START VINYL PRO dub pro vintage, dub pro palmer, dub pro mountain, dub pro loft, dub pro natural, dub pro grace,
dub pro french, dub pro grey, dub pro black, dub pro canyon

START TEX - pvc s textilní podložkou

BLACK B090L, B106L, B136L, B196L, B629L, B636L, B639M, B649M, B669D, B692M, B966M, B970M, B979L, B996D, B997D
TREND TR534, TR536, TR554, TR571, TR593, TR596, TR597
CHROM CH531, C536, CH538, CH542, CH564, CH565, CH590, CH592M, CH592S, CH594T, CH594W, CH597, CH599
TOP T069L, T169M, T620D, T693DC, T693DT, T796M, T906L, T967M

START LINE - zátěžové pvc

VISIO V917, V934, V938 V962, V972, V995, V997, VT26, VT48, VT51, VT89
CENTRO C593B, C593C, C614, C632, C634, C651, C652, C675, C692, C694, C696, C699, C798, CT30, CT92, CT93, CT95, CT96

START CARPET - koberce

RUMBA R02, R12, R14, R15, R25, R30, R37, R40, R60, R77, R80
FOXTROT E70, E73, E74, E75, E76, E77, E293
SPARK

START WOOD - dřevěné podlahy

HDF 327, 678, 779
NOVARA dub primo, dub dibase, dub noce, dub bianco, dub sigaro, dub marrone, dub nero

START LAMINAT - laminátové podlahy

EMOTION 6040, 6112, 6267, 6569, 6575, 6580, 6586, 6588, 6589, 6619

NOVINKA

KONEC